



Remalle

Remalle removes damage to steel/enamel products by Bette, leaving them flawless. Please observe the following safety suggestions and the user instructions:



Process

1. Remove all traces of rust, grease and dirt from the area you wish to treat, and roughen the surface lightly with sandpaper
2. Empty the tube completely and stir the contents
3. Apply a thin layer of the enamel lacquer and allow to dry completely
4. Repeat this process until the damaged area has been filled with the product
5. Remalle repair paste is dry after 10 minutes
6. For optimum results, leave to dry for at least 24 hours
7. Remove any stains with acetone

Safety suggestions

- Highly inflammable
- Keep out of the reach of children
- Keep away from sources of ignition
- Do not smoke
- Do not inhale the vapours
- Take precautionary measures against static discharge
- Avoid contact with the eyes and skin

Item number:
B270-(Colour)

BETTE

Bette GmbH & Co. KG
Heinrich-Bette-Straße 1
33129 Delbrück
Germany

T +49 5250 511-0
F +49 5250 511-130
info@bette.de
www.my-bette.com